



## INSTALLATION INSTRUCTIONS

**MAKE:** Dodge  
**MODEL:** RAM 2500/3500  
**YEAR:** 1994-2002  
**ENGINE:** L6-5.9L (td) Cummins

**Cold Side**  
**Intercooler Tube**  
**46-20067-B (Black)**  
**46-20067-R (Red)**



### Parts Included:

- Tube (46-20067)
- Coupling, Silicone Reducer (05-60421)
- Coupling Hump (05-60012)
- Clamp 3.25" (x2)
- Clamp 3.75" (x2)

### Tools Needed:

- 11mm Deep Socket
- Extension
- Ratchet

**CAUTION:** Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays may reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe Power recommends professional installation on our products.

1. Park vehicle on level ground and apply parking brake, use wheel chocks if necessary.
2. Loosen two (2) clamps on the intake manifold (driver side) and two (2) more clamps at the opposite end of the intercooler tube, then remove tube and couplings from vehicle.
3. Install aFe intercooler couplings onto the aFe tube with clamps and install into vehicle, do not tighten the clamps onto the tube at this point.
4. Ensure tube is not resting on any metal surface, then tighten all clamps.
5. Install is complete.

Enjoy!