



INSTALLATION INSTRUCTIONS

MAKE: Ford
MODEL: F-150
YEAR: 2011-2012
ENGINE: V6-3.5L (tt)

Intercooler
46-20121-1



Parts Included:

- Intercooler
- Plug, Hex (X1)
- Washer, M6 (X1)
- Vent, Breather 1/8" (X1)
- Screw, M6 x 1 x 16 (x1)

Tools Needed:

- 8mm, 10mm, & 13mm socket
- 15mm deep socket
- Flat head screw driver
- Panel popper

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

1. Park vehicle on level ground and engage parking brake.
2. Disconnect battery.
3. Remove the two (2) 15mm nuts holding the plastic shield underneath the vehicle.
4. Remove the plastic clips holding the rubber cover behind the plastic shield just removed.
5. Loosen clamps holding the passenger side intercooler couplings onto the intercooler then disconnect couplings from intercooler.
6. Remove c-clip holding driver side tube onto intercooler then disconnect the tube from intercooler.
7. While supporting the intercooler support bracket, remove the two (2) 13mm bolts to drop the intercooler and support bracket out from the bottom of the vehicle.
8. Install the supplied plug fitting onto the bottom driver side support peg of the aFe intercooler. It is recommended to drain the fluid build-up after every oil change.

Note: There is a breather fitting equipped with this intercooler because testing has shown the stock intercooler may have condensation build up in the bottom of the intercooler on some vehicles. The breather fitting will prevent this issue from happening with no side effects. You can install the breather fitting instead of the plug and never have to drain the intercooler.

9. Install all four rubber grommets and bottom support bracket onto the aFe intercooler then install into vehicle.
10. Use a small amount of WD-40 on outside of grommets for ease of installation.
Note: It may be necessary to reposition top support bracket for installation.
11. Install the two (2) 13mm lower bracket bolts, removed from step 7.
12. Reinstall the passenger side stock couplings, and clamps, onto the aFe intercooler and tighten clamps, using an 8mm socket.
13. Reinstall the driver side tube with c-clip onto the aFe intercooler.
14. Reinstall all parts removed in steps 3 & 4, using a 15mm socket.
15. Reconnect battery.
16. Installation is now complete.

Enjoy and thank you for choosing aFe Power!