



advanced FLOW engineering

Magnum FORCE Stage-2 Air Intake System

Instruction Manual P/N: 51-32322 / 54-32322 / 75-32322

Make: **GM** Model: **Silverado HD/Sierra HD** Year: **2011-2016** Engine: **V8-6.6L (td) LML**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.

Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Air Filter (Pro 5R)	24-91040
A2	1	Air Filter (Pro DRY S)	21-91040
A3	1	Air Filter (Pro-GUARD 7)	72-91040
B	1	Seal, Trim 1/16" (12")	05-00149
C	4	Clamp #064	03-50006
D	3	Screw, M6	03-50113
E	1	Tube	05-32322B1
F	2	Screw, Self Tapping	03-50392
G	2	Coupling, Silicone Hump	05-01201
H	1	Adaptor	05-00611
I	1	Gasket, MAS	05-00631
J	4	Screw, Phillips Self Tapping	03-50416
K	1	Cover, Sensor Plate	05-01227
L	1	Housing	05-32322B2

Installation will require the following tools:
8mm nut driver, Phillips Screwdriver and Torx (T-20) driver.

Warranty Information available at: <https://afepower.com/contact#warranty>



**Figure A****Refer to Figure A for steps 1-4**

Step 1: Disconnect Mass Air Flow sensor, and Humidity Sensor (1).

Step 2: Loosen all tube clamps using an 8mm nut driver (2).

Step 3: Remove OE screws from housing (3).

Step 4: Remove the factory intake tube and top portion of the airbox out of the vehicle (4).



Figure B

Refer to Figure B for step 5

Step 5: Remove the OE filter.



Refer to Figure C for steps 6-8

Step 6: Remove the OE Mass Air Flow sensor and humidity sensor from the factory intake (5).

Step 7: Install MAF sensor and humidity sensor into the aFe intake (6).

On models 2011 and 2012 that do not have a humidity sensor, cover the hole with a gasket and cover plate. Secure with 2 small self threading screws. Do not over tighten.

Step 8: Install furnished silicone hump coupler and clmaps on the aFe tube. (Do not tighten clamps at this time).



Refer to Figure D for steps 9-12

Step 9: Assemble the aFe housing. Install the air filter adaptor with the provided hardware.

Step 10: Install silicon hump couplings and clamps. (Note: tighten adaptor side only).

Step 11: Install seal trim around housing.

Step 12: Install aFe filter. (Tighten clamp).



Figure E

Refer to Figure E for step 13

Step 13: Install aFe housing on top of factory airbox use the 2 screws provided. Do not over tighten (7).



Figure F

Refer to Figure F for steps 14-15

Step 14: Install the aFe intake tube into vehicle, slide the coupling in the turbo inlet tube first. Then slide it into the filter side.

Step 15: Tighten all clamps (8) .

**Figure E****Refer to Figure E for steps 16-17**

- Step 16: Re-connect the MAF sensor and humidity sensor. (If applicable on your application) ⑨ .
- Step 17: Check all the components are tight and secure. Your installation is now complete.

NOTE: Check all bolts, clamps, and connectors after 200 miles. Place enclosed CARB EO sticker on or near the device on a smooth/clean surface. EO identification label is required to pass the smog test inspection.

Page left blank intentionally



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7100