

advanced FLOW engineering

Instruction Manual P/N: 77-46701


Make: **Mitsubishi** Model: **Lancer Evolution X** Year: **2008-2015** Engine: **L4-2.0L (t)**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Module	R77-46701
B	1	LED Switch	05-70005
C	2	Velcro (2" Inches)	05-01244
D	4	Cable Ties	05-60167

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.



**Figure A****Refer to Figure A for Steps 1-2.**

Before installing your aFe module, you will have to place your vehicles ECU in sleep mode. In order to do this you will need to do the following:

- If the engine is cold, open the hood, close the doors, lock the car and wait 30 seconds.
- If the engine is warm, open the hood, close the doors, lock the car and wait 20 minutes.
- If the engine is warm and you can't wait 20 minutes, disconnect the battery.

Step 1: Remove engine cover to gain access to the MAP sensor.

Step 2: Locate the MAP sensor; it is on the intake manifold.




Refer to Figure B for Steps 3-4.

Step 3: Locate and disconnect the MAP sensor.

Step 4: Locate the MAP sensor jumper harness on the aFe module. Plug the male connector of the module to the stock MAP sensor, then take the female connector of the module and connect to the male connector of the engine harness.

Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.



Refer to Figures C for Steps 5-6.

Step 5: Connect the positive (red) wire to a 12V ① power source such as the one pictured.
Step 6: Connect the negative (black) wire ② to a ground such as the one pictured.

**Figure D****Refer to Figure D for Steps 7-8.**

Step 7: Carefully route the switch cable behind steering wheel cover.

Step 8: Mount the Switch on an open, flat surface.

**Figure E****Refer to Figure E for Step 9.**

Step 9: Route the switch cable through firewall and into the engine bay. Follow the main harness through the grommet into the firewall. Plug the end of the cable to the module.



Figure F

Refer to Figure F for Steps 10-11.

Step 10: Mount the module in a safe location, using the supplied Velcro strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties. Make sure all connections are secured and fully engaged.

Step 11: Reinstall the engine cover.



Refer to Figure G for Step 12.


Step 12: When turning on the vehicle, the switch will go through the light. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

Thank you for choosing aFe POWER!



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879